

Move Face

Moves a polysurface face.

Extract Surface

Separates or duplicates polysurface, Extrusion, or SubD faces.

Fold Face

Rotates selected polysurface faces around an axis line.

Extract Wireframe

Creates curves that duplicate surface, polysurface isoparametric curves, and mesh edges displayed in the wireframe view.

Sections

Creates planar curves, points, or hatches by intersecting a plane with the input objects.

Extract Isocurves

Creates curves that duplicate surface isoparametric curves at specified locations on the surface.

Duplicate Face Border

Creates a curve that duplicates a polysurface face border.

Duplicate Border

Creates curves from the boundaries of the selected objects.

Duplicate Edge

Creates curves from the selected surface, mesh or SubD edges.

Remap

Reorients selected objects to a different construction plane.